



BES SERIES - ATMOSPHERIC GAS BOILER
SPARE PARTS LIST





SPARE PARTS														
ITEM	DESCRIPTION	DRAWING NO	PART NUMBER											
			BES - 05	BES - 06	BES - 07	BES - 08	BES - 09	BES - 10	BES - 11	BES - 12	BES - 13	BES - 14	BES - 15	BES - 16
1	LEFT SECTION	BES 00111	BES-111	BES-111	BES-111	BES-111	BES-111	BES-111	BES-111	BES-111	BES-111	BES-111	BES-111	BES-111
2	MIDDLE SECTION	BES 00112	BES-112	BES-112	BES-112	BES-112	BES-112	BES-112	BES-112	BES-112	BES-112	BES-112	BES-112	BES-112
3	RIGHT SECTION	BES 00113	BES-113	BES-113	BES-113	BES-113	BES-113	BES-113	BES-113	BES-113	BES-113	BES-113	BES-113	BES-113
4	FLUE GAS COLLECTOR	BES 00114	BES-114.001	BES-114.002	BES-114.003	BES-114.004	BES-114.005	BES-114.006	BES-114.007	BES-114.008	BES-114.009	BES-114.010	BES-114.011	BES-114.012
5	INSULATION ROPES	BES 00115	BES-115	BES-115	BES-115	BES-115	BES-115	BES-115	BES-115	BES-115	BES-115	BES-115	BES-115	BES-115
6	CONNECTION RODS	BES 00116	BES-116.001	BES-116.002	BES-116.003	BES-116.004	BES-116.005	BES-116.006	BES-116.007	BES-116.008	BES-116.009	BES-116.010	BES-116.011	BES-116.012
7	WATER COLLECTOR	BES 00117	BES-117.001	BES-117.002	BES-117.003	BES-117.004	BES-117.005	BES-117.006	BES-117.007	BES-117.008	BES-117.009	BES-117.010	BES-117.011	BES-117.012
8	WATER INLET-OUTLET FLANGE	BES 00118	BES-118	BES-118	BES-118	BES-118	BES-118	BES-118	BES-118	BES-118	BES-118	BES-118	BES-118	BES-118
9	FLANGE GASKET	BES 00119	BES-119	BES-119	BES-119	BES-119	BES-119	BES-119	BES-119	BES-119	BES-119	BES-119	BES-119	BES-119
10	THERMOSTAT BULB	BES 00120	BES-120	BES-120	BES-120	BES-120	BES-120	BES-120	BES-120	BES-120	BES-120	BES-120	BES-120	BES-120
11	FRONT SIDE INSULATION PLATE	BES 00121	BES-121.001	BES-121.002	BES-121.003	BES-121.004	BES-121.005	BES-121.006	BES-121.007	BES-121.008	BES-121.009	BES-121.010	BES-121.011	BES-121.012
12	BURNER COVER INSULATION	BES 00122	BES-122.001	BES-122.002	BES-122.003	BES-122.004	BES-122.005	BES-122.006	BES-122.007	BES-122.008	BES-122.009	BES-122.010	BES-122.011	BES-122.012
13	IGNITION ELECTRODE	BES 00123	BES-123	BES-123	BES-123	BES-123	BES-123	BES-123	BES-123	BES-123	BES-123	BES-123	BES-123	BES-123
14	ATMOSPHERIC BURNER	BES 00124	BES-124	BES-124	BES-124	BES-124	BES-124	BES-124	BES-124	BES-124	BES-124	BES-124	BES-124	BES-124
15	BURNER CONNECTION COVER	BES 00125	BES-125.001	BES-125.002	BES-125.003	BES-125.004	BES-125.005	BES-125.006	BES-125.007	BES-125.008	BES-125.009	BES-125.010	BES-125.011	BES-125.012
16	IONISATION ELECTRODE	BES 00126	BES-126	BES-126	BES-126	BES-126	BES-126	BES-126	BES-126	BES-126	BES-126	BES-126	BES-126	BES-126
17	SILICON CABLE FOR IGNITION	BES 00127	BES-127	BES-127	BES-127	BES-127	BES-127	BES-127	BES-127	BES-127	BES-127	BES-127	BES-127	BES-127
18	SILICON CABLE FOR IONISATION	BES 00128	BES-128	BES-128	BES-128	BES-128	BES-128	BES-128	BES-128	BES-128	BES-128	BES-128	BES-128	BES-128
19	FLAME OBSERVATION WINDOW	BES 00129	BES-129	BES-129	BES-129	BES-129	BES-129	BES-129	BES-129	BES-129	BES-129	BES-129	BES-129	BES-129
20	GAS COLLECTOR SET	BES 00130	BES-130.001	BES-130.002	BES-130.003	BES-130.004	BES-130.005	BES-130.006	BES-130.007	BES-130.008	BES-130.009	BES-130.010	BES-130.011	BES-130.012
21	GAS VALVE OUTLET FLANGE	BES 00131	BES-131	BES-131	BES-131	BES-131	BES-131	BES-131	BES-131	BES-131	BES-131	BES-131	BES-131	BES-131
22	GAS VALVE OUTLET O-RING	BES 00132	BES-132	BES-132	BES-132	BES-132	BES-132	BES-132	BES-132	BES-132	BES-132	BES-132	BES-132	BES-132
23	GAS VALVE	BES 00133	BES-133.001	BES-133.001	BES-133.002	BES-133.002	BES-133.002	BES-133.003	BES-133.004	BES-133.004	BES-133.005	BES-133.005	BES-133.005	BES-133.005
24	GAS VALVE INLET FLANGE	BES 00134	BES-134	BES-134	BES-134	BES-134	BES-134	BES-134	BES-134	BES-134	BES-134	BES-134	BES-134	BES-134
25	GAS PIPE	BES 00135	BES-135	BES-135	BES-135	BES-135	BES-135	BES-135	BES-135	BES-135	BES-135	BES-135	BES-135	BES-135
26	CONTROL PANEL PLASTIC PLATE	BES 00136	BES-136	BES-136	BES-136	BES-136	BES-136	BES-136	BES-136	BES-136	BES-136	BES-136	BES-136	BES-136
27	STOPPER - BLIND FLANGE	BES 00137	BES-137	BES-137	BES-137	BES-137	BES-137	BES-137	BES-137	BES-137	BES-137	BES-137	BES-137	BES-137
28	THERMOMETER	BES 00138	BES-138	BES-138	BES-138	BES-138	BES-138	BES-138	BES-138	BES-138	BES-138	BES-138	BES-138	BES-138
29	BOILER CONTROL THERMOSTATE	BES 00139	BES-139	BES-139	BES-139	BES-139	BES-139	BES-139	BES-139	BES-139	BES-139	BES-139	BES-139	BES-139
30	THERMOSTATE ADJUSTMENT CAP	BES 00140	BES-140	BES-140	BES-140	BES-140	BES-140	BES-140	BES-140	BES-140	BES-140	BES-140	BES-140	BES-140
31	LIMIT THERMOSTATE	BES 00141	BES-141	BES-141	BES-141	BES-141	BES-141	BES-141	BES-141	BES-141	BES-141	BES-141	BES-141	BES-141
32	FUSE	BES 00142	BES-142	BES-142	BES-142	BES-142	BES-142	BES-142	BES-142	BES-142	BES-142	BES-142	BES-142	BES-142
33	ON/OFF BUTTON	BES 00143	BES-143	BES-143	BES-143	BES-143	BES-143	BES-143	BES-143	BES-143	BES-143	BES-143	BES-143	BES-143
34	INDICATOR LAMP	BES 00144	BES-144	BES-144	BES-144	BES-144	BES-144	BES-144	BES-144	BES-144	BES-144	BES-144	BES-144	BES-144
35	RESET BUTTON	BES 00145	BES-145	BES-145	BES-145	BES-145	BES-145	BES-145	BES-145	BES-145	BES-145	BES-145	BES-145	BES-145
36	BOTTOM AIR HOLES - SIDE	BES 00146	BES-146	BES-146	BES-146	BES-146	BES-146	BES-146	BES-146	BES-146	BES-146	BES-146	BES-146	BES-146
37	BOTTOM AIR HOLES - FRONT AND REAR	BES 00147	BES-147.001	BES-147.002	BES-147.003	BES-147.004	BES-147.005	BES-147.006	BES-147.007	BES-147.008	BES-147.009	BES-147.010	BES-147.011	BES-147.012
38	FRONT COVER PANEL	BES 00148	BES-148.001	BES-148.002	BES-148.003	BES-148.004	BES-148.005	BES-148.006	BES-148.007	BES-148.008	BES-148.009	BES-148.010	BES-148.011	BES-148.012
39	LEFT COVER PANEL	BES 00149	BES-149	BES-149	BES-149	BES-149	BES-149	BES-149	BES-149	BES-149	BES-149	BES-149	BES-149	BES-149
40	RIGHT COVER PANEL	BES 00150	BES-150	BES-150	BES-150	BES-150	BES-150	BES-150	BES-150	BES-150	BES-150	BES-150	BES-150	BES-150
41	REAR COVER PANEL	BES 00151	BES-151.001	BES-151.002	BES-151.003	BES-151.004	BES-151.005	BES-151.006	BES-151.007	BES-151.008	BES-151.009	BES-151.010	BES-151.011	BES-151.012
42	TOP COVER PANEL	BES 00152	BES-152.001	BES-152.002	BES-152.003	BES-152.004	BES-152.005	BES-152.006	BES-152.007	BES-152.008	BES-152.009	BES-152.010	BES-152.011	BES-152.012
43	FLUE GAS LIMIT THERMOSTATE	BES 00153	BES-153	BES-153	BES-153	BES-153	BES-153	BES-153	BES-153	BES-153	BES-153	BES-153	BES-153	BES-153
44	NIPPLES	BES 00154	BES-154	BES-154	BES-154	BES-154	BES-154	BES-154	BES-154	BES-154	BES-154	BES-154	BES-154	BES-154
45	BODY INSULATION	BES 00155	BES-155.001	BES-155.002	BES-155.003	BES-155.004	BES-155.005	BES-155.006	BES-155.007	BES-155.008	BES-155.009	BES-155.010	BES-155.011	BES-155.012
46	FRONT SIDE INSULATION	BES 00156	BES-156.001	BES-156.002	BES-156.003	BES-156.004	BES-156.005	BES-156.006	BES-156.007	BES-156.008	BES-156.009	BES-156.010	BES-156.011	BES-156.012
47	CONTROL PANEL INSULATION	BES 00157	BES-157.001	BES-157.002	BES-157.003	BES-157.004	BES-157.005	BES-157.006	BES-157.007	BES-157.008	BES-157.009	BES-157.010	BES-157.011	BES-157.012
48	TOP SIDE INSULATION	BES 00158	BES-158.001	BES-158.002	BES-158.003	BES-158.004	BES-158.005	BES-158.006	BES-158.007	BES-158.008	BES-158.009	BES-158.010	BES-158.011	BES-158.012
49	IGNITION CONTROL CARD	BES 00159	BES-159.001	BES-159.002	BES-159.003	BES-159.004	BES-159.005	BES-159.006	BES-159.007	BES-159.008	BES-159.009	BES-159.010	BES-159.011	BES-159.012
50	CONTROL PANEL BOX	BES 00160	BES-160	BES-160	BES-160	BES-160	BES-160	BES-160	BES-160	BES-160	BES-160	BES-160	BES-160	BES-160
51	CHASSIS	BES 00161	BES-161.001	BES-161.002	BES-161.003	BES-161.004	BES-161.005	BES-161.006	BES-161.007	BES-161.008	BES-161.009	BES-161.010	BES-161.011	BES-161.012

